

TOTAL BODY ENHANCEMENT BEAUTY LIGHT




INTERIOR DISPLAY

VIBRA SHAPE OPTIONS


1 WELLNESS (LOW INTENSITY)

This program improves flexibility, loosens and relaxes muscles with gentle movements at low-impact vibration frequency.




2 NEW YOU (MEDIUM INTENSITY)

Designed for beginners, this program utilizes medium frequency vibration and massage technology to gradually improve muscle tone appearance with controlled, alternating movements.




3 CROSS-TRAINING (HIGH INTENSITY)

Using intense vibration combined with high frequency interval training, this program strengthens muscles with powerful movements. It's excellent for sports and exercise enthusiasts.



4 MULTI-LEVEL (MIXED INTENSITY)

A mixed frequency cycle targets specific muscle groups in the legs, abs, arms and glutes to help tone and tighten muscles. This program provides an energizing workout.



1 START/STOP

The lamps in the TBE are started by the front desk. If the unit is connected to a control system, the lamps automatically turn on at the end of the programmed delay period. If desired, you can also start the lamps immediately by pressing the Start / Stop button on the control panel. You can press and hold the Start / Stop button to turn off the lamps at any point during your session. Press the button again to restart the lamps. Interruptions may count as part of your continuously running scheduled session time.

2 PLUS AND MINUS KEYS

To adjust the selected function, press the plus or minus buttons to increase or decrease the setting. Continue to press and release the plus or minus buttons until the desired intensity is reached. In order to make a major adjustment, you must tap the button several times. Please do not press and hold down these buttons.

3 ARROW KEYS

Use the Left or Right arrow keys to navigate to the function of the Beauty Angel you would like to adjust. Once selected, the indicator for the feature will begin to flash. In order to make a major adjustment, you must tap the button several times. Please do not press and hold down these buttons.

4 BODY VENTILATION

The TBE body ventilation system offers two convenient settings – automatic and manual. Once a session begins, the body ventilation will begin to gently increase in intensity with the progress of the session. Body ventilation can also be adjusted to the setting you desire by selecting the body ventilation feature and then pressing the plus or minus buttons.

5 VIBRA SHAPE

The TBE features Vibra Shape. By selecting this feature you may choose between four programs – from gentle to intense. Place your feet as indicated on the floor mat, stay relaxed and do not lock your knees to ensure maximum effectiveness. For your safety, use the air vent poles to steady yourself during operation of the Vibra Shape. Vibration intensity and power levels fluctuate throughout the session so you should be prepared for changes. Please consult your physician if you have medical concerns regarding the use of the Vibra Shape feature or if you have or previously had any condition affecting the bones, bone density, or bone irregularities. Persons who are pregnant or experience acute illness/infection should not use the Vibra Shape feature. Discontinue use immediately if you experience dizziness or nausea.

6 BLUETOOTH CONNECT

Easy to operate, just press the Bluetooth key, activate the connection with your smartphone and enjoy your favorite music. During the tanning session you can change between songs with the plus or minus keys on the control panel. If the Bluetooth connection is interrupted or lost, you can re-connect using the Control Panel.

7 MUSIC

With the plus and minus keys, you can select between different music channels.

8 VOLUME

With the plus and minus keys, you can adjust the volume of the music.

9 VOICE GUIDE

This feature provides details on the functions available as well as important information during the process. With the plus and minus keys, you can turn the Voice Guide ON or OFF.